



WHAT YOU'LL NEED

Specific hardware required to make designs on macarons/macaroons

Ripple Maker II Platform Pods





















click here to see the tutorial video https://youtu.be/ogX1LMvlja4



SETTINGS FOR MACARONS – STEP 1


Follow the below settings for the best designs on macarons

We recommend using lighter coloured macarons for best designs

Change optical density to your preference based on time needed to dry.

Our recommendation is 50%.

Set print quality to "Standard"





SETTINGS FOR MACARONS – STEP 2

Make sure you follow these steps for the correct procedure

Remove the silicone mat

Place the platform in the tray and ensure it fits properly with nothing blocking it.

Make sure the "Ripples" wording on the platform is front facing.

Place the macarons correctly in each of the 3 spaces on the top of the platform.











PRINTING ON MACARONS

Choose your own creation or from a list of pre-defined designs

Pre-defined designs


Ensure the platform is secure in the tray and the macarons are placed correctly in the platform



Simply select the channel from the drop-down menu under "MACARONS" or scroll down to the desired channel

Choose your desired design and press to print

Enjoy!















UPLOADING THE WEBAPP SKIN

Uploading the correct webapp skin in the Cloud to unlock the feature to customize Macarons – NB for Enhanced or Enterprise Service plans only

Go to your Cloud account and scroll down and select "Locations"



Go to the location you wish to change and click the chain icon on the right-hand side



Go to the Skin drop down list and select the "Default Macaron" webapp skin



you're done

Skin: Default Macaron






CUSTOMISE YOUR MACARON – 1/2

Customise your own Macaron through the Web App

Custom designs

Scan the QR code associated with the Ripple Maker II and go to the WebApp




Location: Emily's Coffee Shop


ABOUT




Select the Macaron icon Choose how many Macarons you want to customise Select which Macaron to customize. Note the position on the screen will match up to the placement of macaron on the platform

Select "Create my own" or you can choose from an existing design











CUSTOMISE YOUR MACARON – 2/2

Customise your own Macaron through the Web App

A help screen will appear if you are unsure, click "Got it" to continue



Select the text tile and double click "Your text" to



Change your font, pinch in and out to adjust size, then click "Done"




Repeat the process for the rest of the Macarons



Review all 3 of your Macarons



Once complete select "Let's print", this generates a queue number. Select your queue number and print.





ADDING PERMANENT DESIGNS – 1/3

Adding designs to your device through the mobile portal

Scan the QR code associated with the Ripple Maker II and go to the WebApp



ABOUT


Location: Emily's Coffee Shop



Click on the icon in the top right corner to login to the mobile portal



Click on the "Create" icon



Click on the "Macaron" icon



Select how many Macarons you want to customise






ADDING PERMANENT DESIGNS – 2/3

Select the Macaron you wish to customize e.g. number 1 Select if you wish to "Create your own" or choose from a previous design


Upload your image, click "Add photo"

Edit your uploaded image, make it bigger or smaller, center it or adjust its position. You can also adjust the filter, then click "Done"

You will now see a preview of your design for your 1st macaron. If you wish to duplicate the image to all 3 then click the 3 dots and select "Duplicate"














ADDING PERMANENT DESIGNS – 3/3





THANK YOU