

RIPPLE MAKER II & RIPPLE MAKER II PRO GUIDE





PRINTING ON DRINKS

Choose your own creation or from a list of pre-defined designs

Pre-defined designs


Ensure the glass is placed in the center of the tray within the white circle. Remember to have the glass logo, if any, facing the left-hand side.


Simply select the channel of choice from the drop-down menu or scroll down to the desired channel e.g. Guinness

Choose your desired design and press to print

Enjoy!











CUSTOMISE YOUR DRINK

Customize your own drink through the Web App with a photo




Next step is to choose the best filter, creating the best contrasting image.



Custom designs


Scan the QR code associated with the Ripple Maker and go to the Web App






Select the "Photo" icon





Once you upload your photo you can move it around to fit within the frame




Once complete select "Let's print", this generates a queue number. Select your queue number and print from the "Mobile" tab on the Ripple Maker.

Click on your design to print

Click "Print another" to create another design.

You can also pinch the image to make it larger or smaller to best fit the frame








CUSTOMISE YOUR MACARON – 1/2

Customize your own Macaron through the Web App






To Watch the YouTube Tutorial Click Here Full Macaron Tutorial Article Click Here



CUSTOMISE YOUR MACARON – 2/2

Customize your own Macaron through the Web App



queue number

and print.

P Ripples

A help screen will appear if you are unsure, click "Got it" to continue



ripples™

€ 100% € 100%

Notifications

Training

Settings

Reports

Support

Notificatio

Settings

Reports

Support

About

Replace Pod

Maintenance

R

CUSTOMISE YOUR DRINK

Customize your own drink through the **Web App with text**



Custom designs You can also pinch Keypad should pop up, Double tap the the image to make it enter your desired text "Your Text" to Scan the QR code associated with Select the "Text" icon and click "I'm done" larger or smaller to the RM and go to the WebApp edit the text best fit the frame when ready • • • • • • • • • UNG UNG Т (i) Т HAPPY YOUR ripples TEX Happy Birthday Jenny LET'S START! New A selfie? A greeting? I'M DONE Anything goes $\left(1 = \right)$ New AA AA Aa Aa Aa Aa 🗛 ·AA· Photo Surprise 火が LET'S PRIN LET'S PRINT UNG AMSUNG SUNG Т Т Finally select Click on your design to R Select your queue Here you your desired print number and print can YOU DID IT! HAPPY frame, Happy Birthday Show our staff your number from the "Mobile" change position BIRTHDAY JENNY Click "Print another" to 5 Jenny the text tab on the Ripple correctly and create another design. Maker. alignment WEB APP QR CODE select "Let's as well as o an o Choose a frame Print" Scan to use web app the Aa Aa AA AA desired -The -Instagram 0 font LET'S PRINT LET'S PRINT




SETTINGS FOR DRINKS – OPTION 1


Follow the below settings for the best ripples on drinks

Click on the "Settings" tab in the menu list

Select the "Printing" tab

Unclick the "Auto" button under "Print Quality" and set print quality to "Enhanced" Set your preferred cup size here as your default size. You can go in between sizes by clicking the pencil and then selecting a measure on the ruler.













SETTINGS FOR DRINKS – OPTION 2

If you wish to change the size of a single print, follow the below instructions

Long tap/hold on the design you wish to print

Select the preferred size you want to print and or the POD type you wish to use Select "Print". Note that only this print will change the size. The next print will set back to the default print size as setup in Settings

Select "Cancel" if you wish to cancel the print or close the screen when you are finished













SETTING YOUR POD TYPE


Here you can set your default Pod type for Ripple Maker II Pro versions

Click on the "Settings" tab in the menu list

Select the "Printing" tab

Make sure the "Multicolor" function is toggled as on. Here you can now select your default pod type.

Ripple Maker II Pro Only




To Watch the YouTube Tutorial Click Here





DAILY MAINTENANCE

We recommend doing this daily as it helps with optimizing print quality



Watch the YouTube Tutorial Click Here




REPLACING THE POD


Follow the steps below to correctly change the POD

RIPPLE MAKER II – Watch the YouTube Tutorial Click Here RIPPLE MAKER II PRO– Watch the YouTube Tutorial Click Here


Open the menu and select the "REPLACE POD" tab



Important to take care when handling the POD as they are fragile. Keep an eye out for any damage to the POD.



Select the "POD Replacement" tab under "Maintenance"




Remember to handle the POD with care and only use 2 fingers of pressure



Follow the onboard prompts and click "Next"



Follow the onboard prompts and click "Finish"






UPDATING CONTENT

This shows how to update and/or sync content

Click on the "Settings" tab in the menu list

Select the "Content" tab

Click the "Sync" button to sync the latest content Allow a few seconds to update. You should now have an updated sync time.








CONNECTIVITY SETTINGS

Follow the below settings to connect to a network

Click on the "Settings" tab in the menu list Select the "Connectivity" tab and click the "Change" button

Scroll to find the desired network and click "Connect" Type in the password, then click "Connect"







CONNECTIVITY SETTINGS

Connecting to a hidden network, follow the below steps


Click on the "Settings" tab in the menu list Select the "Connectivity" tab and click the "Change" button

Scroll to the bottom and click "Add Network" Type in the network name and password, then click "Connect"

 \propto

enter

φ








PRINT QUALITY

How to improve your print quality

Click on the "Maintenance" tab in the menu list Select the "Print Quality" tab and click the "Start Test Print" button (make sure you have a cup with paper to run a test print) Scroll through the onscreen examples to find your issue, click the suggestion and follow the onboard messages

Run another test print to see if the issue has been resolved.














REPORTS

How to manually check your print numbers on the Ripple Maker II

Click on the "Reports" tab in the menu list Here you can manually view your print numbers by day in the "Week" view Toggle to "Month" to view the weeks in the month Click the previous arrow to view the previous months prints








TRAINING

Training on all things Ripple Maker right from your Ripple Maker screen.








CONTACT SUPPORT

If you need any extra assistance, please contact support

Simply click on the "About" button to access support contact details



Either scan the QR code to open a WhatsApp conversation, click on the "Open a service call" button or email to contact support





<u>support@drinkripples.com</u> Click here for Full Contact Details



THANK YOU